

CHAPTER 5. I.C. Engine Parts

- Piston
- Connecting Rod
- Crank Shaft and flywheel


DIGITAL LINK FOR ASSEMBLY OF CONNECTING ROD

1 https://youtu.be/ABbf_Pa6SV0




2 <https://youtu.be/ZoCn4Pb6rLU>

3 <https://youtu.be/HPyx9MmAkN8>


Piston (Petrol Engine)



1




Connecting Rod




Parts list

Part No.	Name	Matl.	Qty.
1	Rod	FS	1
2	Cap	FS	1
3	Bearing brass	GM	2
4	Bearing bush	P Bronze	1
5	Bolt	MCS	2
6	Nut	MCS	2

Crank Shaft and Flywheel



FLYWHEEL



CRANKSHAFT

